



SISTEMA DE MULTICONMUTADORES
MULTISWITCH SYSTEM
MULTISWITCH SISTEMI
SYSTÈME MULTICOMMUTATEUR



SERIE 913 SERIES

MULTICONMUTADORES - MULTISWITCHES- MULTISWITCH'LER - MULTICOMMUTATEURS

CÓDIGO-CODE-CODE	9130079	9130080	9130081				
MODELO-MODEL-MODELE	MB-302	MB-303	MB-304				
Entradas/salidas/derivaciones Inputs/outputs/taps Giriş/çıkış/yen çıkış Entrées/sorties/dérivations		13/0/8	13/0/12				
Rango de frecuencia Frequency range Frekans Gamme de fréquences	Band MHz	TV 47-862	SAT 950-2150	TV 47-862	SAT 950-2150	TV 47-862	SAT 950-2150
MODO PASIVO - PASSIVE MODE - PASIF DURUM - MODE PASSIF							
Atenuación de derivación Tap loss Yan çıkış kaybı Atténuation de dérivation	dB ±TOL	20 ±2,0	0 ±2,0	21 ±2,0	1 ±2,0	21 ±2,0	1 ±2,0
Nivel de salida Output level Çıkış seviyesi Niveau de sortie	dBµV	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)
MODO ACTIVO - ACTIVE MODE - AKTİF DURUM - MODE ACTIF							
Atenuación de derivación Tap loss Yan çıkış kaybı Atténuation de dérivation	dB ±TOL	0 ±2,0	0 ±2,0	1 ±2,0	1 ±2,0	1 ±2,0	1 ±2,0
Nivel de salida Output level Çıkış seviyesi Niveau de sortie	dBµV	99 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	96 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	96 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)
MODO ACTIVO/PASIVO - ACTIVE/PASSIVE MODE - AKTİF/PASİF DURUM - MODE ACTIF/PASSIF							
Equalización de derivación Tap equalization Yan çıkış eğimi Égalisation de dérivation	dB	3	3	2	3	2	3
Rechazo entre bandas Rejection between bands Girişler arası izolasyon Rejection entre bandes	dB				>25 TV/SAT >65 SAT/TV		
Desacoplo entre usuarios Isolation between users Yan çıkışlar arası izolasyon Découplage entre utilisateurs	dB				>25 TV >30 SAT		
Desacoplo de conmutación Isolation of switching Anatharma Découplage de commutation	dB				>30 SAT/SAT		
Comutación de las salidas Switching the outputs Uydu seçimi Commutation des sorties					DiSEqC 2.0 14 V ₊ /18 V ₋ 0/22 KHz		
Alimentación de las LNB Power supply of the LNB LNB besleme Alimentation des LNB					2050 mA / 13 V _{...}		
Consumo desde el receptor Consumption from the receiver Uydu alıcısından çekilen akım Consommation du récepteur	mA				42 ±2,0 (14/18 V _{...})		

IMD₃ -35 dB: 2 equal carriers, EN 50083-5

IMD₂ -35 dB: 2 equal carriers, EN 50083-5

Data published in compliance with the definitions and measurement methods of the following standards: EN 50083-3, EN 50083-4 and EN 50083-5

MULTICONMUTADORES - MULTISWITCHES- MULTISWITCH'LER - MULTICOMMUTATEURS

CÓDIGO-CODE-CODE	9130082	9130083	9130172				
MODELO-MODEL-MODELE	MB-305	MB-306	MB-308				
Entradas/salidas/derivaciones Inputs/outputs/taps Giriş/çıkış/yen çıkış Entrées/sorties/dérivations		13/0/20	13/0/24				
Rango de frecuencia Frequency range Frekans Gamme de fréquences	Band MHz	TV 47-862	SAT 950-2150	TV 47-862	SAT 950-2150	TV 47-862	SAT 950-2150
MODO PASIVO - PASSIVE MODE - PASIF DURUM - MODE PASSIF							
Atenuación de derivación Tap loss Yan çıkış kaybı Atténuation de dérivation	dB ±TOL	22 ±2,0	2 ±2,0	22 ±2,0	2 ±2,0	24 ±2,0	5 ±2,0
Nivel de salida Output level Çıkış seviyesi Niveau de sortie	dBµV	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)
MODO ACTIVO - ACTIVE MODE - AKTİF DURUM - MODE ACTIF							
Atenuación de derivación Tap loss Yan çıkış kaybı Atténuation de dérivation	dB ±TOL	2 ±2,0	2 ±2,0	2 ±2,0	2 ±2,0	4 ±2,0	5 ±2,0
Nivel de salida Output level Çıkış seviyesi Niveau de sortie	dBµV	95 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	95 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	95 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)
MODO ACTIVO/PASIVO - ACTIVE/PASSIVE MODE - AKTİF/PASİF DURUM - MODE ACTIF/PASSIF							
Equalización de derivación Tap equalization Yan çıkış eğimi Égalisation de dérivation	dB	1	2	1	2	1	2
Rechazo entre bandas Rejection between bands Girişler arası izolasyon Rejection entre bandes	dB				>25 TV/SAT >65 SAT/TV		
Desacoplo entre usuarios Isolation between users Yan çıkışlar arası izolasyon Découplage entre utilisateurs	dB				>25 TV >30 SAT		
Desacoplo de conmutación Isolation of switching Anatharma Découplage de commutation	dB				>30 SAT/SAT		
Comutación de las salidas Switching the outputs Uydu seçimi Commutation des sorties					DiSEqC 2.0 14 V ₊₌ / 18 V ₊₌ 0/22 KHz		
Alimentación de las LNB Power supply of the LNB LNB besleme Alimentation des LNB					2050 mA / 13 V ₊₌		
Consumo desde el receptor Consumption from the receiver Uydu alıcıından çekilen akım Consommation du récepteur	mA				42 ±2,0 (14/18 V ₊₌)		

IMD₃ -35 dB: 2 equal carriers, EN 50083-5

IMD₂ -35 dB: 2 equal carriers, EN 50083-5

Data published in compliance with the definitions and measurement methods of the following standards: EN 50083-3, EN 50083-4 and EN 50083-5


MULTICONMUTADORES - MULTISWITCHES- MULTISWITCH'LER - MULTICOMMUTATEURS

CÓDIGO-CODE-CODE	9130114	9130115	9130116				
MODELO-MODEL-MODELE	ML-302	ML-303	ML-304				
Entradas/salidas/derivaciones Inputs/outputs/taps Giriş/çıkış/yen çıkış Entrées/sorties/dérivations		13/13/8	13/13/12	13/13/16			
Rango de frecuencia Frequency range Frekans Gamme de fréquences	Band MHz	TV 47-862	SAT 950-2150	TV 47-862	SAT 950-2150	TV 47-862	SAT 950-2150
MODO PASIVO - PASSIVE MODE - PASIF DURUM - MODE PASSIF							
Atenuación de derivación Tap loss Yan çıkış kaybı Atténuation de dérivation	dB ±TOL	22 ±2,0	0 ±2,0	24 ±2,0	1 ±2,0	24 ±2,0	1 ±2,0
Nivel de salida Output level Çıkış seviyesi Niveau de sortie	dBµV	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)
MODO ACTIVO - ACTIVE MODE - AKTİF DURUM - MODE ACTIF							
Atenuación de derivación Tap loss Yan çıkış kaybı Atténuation de dérivation	dB ±TOL	2 ±2,0	0 ±2,0	4 ±2,0	1 ±2,0	4 ±2,0	1 ±2,0
Nivel de salida Output level Çıkış seviyesi Niveau de sortie	dBµV	99 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	96 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	96 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)
MODO ACTIVO/PASIVO - ACTIVE/PASSIVE MODE - AKTİF/PASİF DURUM - MODE ACTIF/PASSIF							
Equalización de derivación Tap equalization Yan çıkış eğimi Egalisation de dérivation	dB	3	3	2	3	2	3
Atenuación de paso Through loss Geçiş kaybı Atténuation de passage	dB ±TOL	4,5 ±1,0	2,0 ±1,0	4,5 ±1,0	3,0 ±1,0	4,5 ±1,0	4,0 ±1,0
Rechazo entre bandas Rejection between bands Girişler arası izolasyon Rejection entre bandes	dB			>25	TV/SAT	>65	SAT/TV
Desacoplo entre usuarios Isolation between users Yan çıkışlar arası izolasyon Découplage entre utilisateurs	dB			>25	TV	>30	SAT
Desacoplo de conmutación Isolation of switching Anahatma Découplage de commutation	dB			>30	SAT/SAT		
Comutación de las salidas Switching the outputs Uydu seçimi Commutation des sorties				DiSEqC 2.0 14 V _{cc} / 18 V _{cc} 0/22 KHz			
Alimentación de las LNB Power supply of the LNB LNB besleme Alimentation des LNB				2050 mA / 13 V _{cc}			
Consumo desde el receptor Consumption from the receiver Uydu alıcılarından çekilen akım Consommation du récepteur	mA			42 ±2,0 (14/18 V _{cc})			

MULTICONMUTADORES - MULTISWITCHES- MULTISWITCH'LER - MULTICOMMUTATEURS

CÓDIGO-CODE-CODE	9130117	9130118	9130173				
MODELO-MODEL-MODELE	ML-305	ML-306	ML-308				
Entradas/salidas/derivaciones Inputs/outputs/taps Giriş/çıkış/yen çıkış Entrées/sorties/dérivations	13/13/20	13/13/24	13/13/32				
Rango de frecuencia Frequency range Frekans Gamme de fréquences	Band MHz	TV 47-862	SAT 950-2150	TV 47-862	SAT 950-2150	TV 47-862	SAT 950-2150
MODO PASIVO - PASSIVE MODE - PASIF DURUM - MODE PASSIF							
Atenuación de derivación Tap loss Yan çıkış kaybı Atténuation de dérivation	dB ±TOL	26 ±2,0	2 ±2,0	26 ±2,0	2 ±2,0	26 ±2,0	4 ±2,0
Nivel de salida Output level Çıkış seviyesi Niveau de sortie	dBµV	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	110 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)
MODO ACTIVO - ACTIVE MODE - AKTİF DURUM - MODE ACTIF							
Atenuación de derivación Tap loss Yan çıkış kaybı Atténuation de dérivation	dB ±TOL	6 ±2,0	2 ±2,0	6 ±2,0	2 ±2,0	6 ±2,0	4 ±2,0
Nivel de salida Output level Çıkış seviyesi Niveau de sortie	dBµV	95 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	95 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)	95 (DIN 45004B)	100 (IMD ₃ -35 dB) 90 (IMD ₂ -35 dB)
MODO ACTIVO/PASIVO - ACTIVE/PASSIVE MODE - AKTİF/PASİF DURUM - MODE ACTIF/PASSIF							
Equalización de derivación Tap equalization Yan çıkış eğimi Egalisation de dérivation	dB	1	2	1	2	1	2
Atenuación de paso Through loss Geçiş kaybı Atténuation de passage	dB ±TOL	4,5 ±1,0	4,0 ±1,0	4,5 ±1,0	4,0 ±1,0	5,0 ±2,0	4,5 ±2,0
Rechazo entre bandas Rejection between bands Girişler arası izolasyon Rejection entre bandes	dB				>25 TV/SAT >65 SAT/TV		
Desacoplo entre usuarios Isolation between users Yan çıkışlar arası izolasyon Découplage entre utilisateurs	dB				>25 TV >30 SAT		
Desacoplo de conmutación Isolation of switching Anahatma Découplage de commutation	dB				>30 SAT/SAT		
Comutación de las salidas Switching the outputs Uydu seçimi Commutation des sorties					DiSEqC 2.0 14 V _{cc} / 18 V _{cc} 0/22 KHz		
Alimentación de las LNB Power supply of the LNB LNB besleme Alimentation des LNB					2050 mA / 13 V _{cc}		
Consumo desde el receptor Consumption from the receiver Uydu alıcılarından çekilen akım Consommation du récepteur	mA				42 ±2,0 (14/18 V _{cc})		

CÓMO ALIMENTAR LOS MULTISWITCHES
HOW TO FEED THE MULTISWITCH
MULTISWITCH BEŞLEMESİ
COMMENT ALIMENTER LE MULTICOMMUTATEUR




INSTALACIÓN DE LNBS
INSTALLING LNB
LNB KULLANIMI
INSTALLATION DES LNB

QUATRO




High Horizontal
High Vertical
Low Horizontal
Low Vertical


CONMUTACIÓN DE LAS SALIDAS SWITCHING THE OUTPUTS UYDU SECİMİ COMMUTATION DES SORTIES




CONMUTADOR ACTIVO/PASIVO
ACTIVE-PASSIVE SWITCH
AKTİF-PASİF ANAHTAR
INTERREPTEUR ACTIF-PASSIF



LED DE CONEXIÓN DE USUARIO
USER CONNECTION LED
ABONE BAĞLANTI LEDİ
LED DE CONNEXION DE L'UTILISATEUR




PREAMPLIFICACIÓN DE LA SEÑAL DE ANTENA
PREAMPLIFICATION OF THE ANTENNA SIGNAL
ÖN YÜKSELTİCİ BAĞLANTISI
PRE AMPLIFICATION DU SIGNAL D'ANTENNE




13 x 8


Modo activo / Active mode / Aktif durum / Mode actif



Modo activo / Active mode / Aktif durum /Mode actif



Modo activo / Active mode / Aktif durum /Mode actif



Instrucciones de seguridad

No exponga el alimentador a goteo o proyecciones de agua. No sitúe objetos llenos de líquido, como vasos, sobre el equipo. No sitúe fuentes de llama desnuda, tales como velas encendidas, sobre el equipo. No cubra las aberturas de ventilación del equipo con objetos, tales como periódicos, cortinas, etc. Instale el equipo dejando un espacio libre alrededor para disponer de una ventilación suficiente. Instale el equipo de modo que la clavija de red de alimentación o el conector del equipo sean fácilmente accesibles.

Safety Instructions

Do not place the power supply where water can drip or splash onto it. Do not place objects containing liquid, such as glasses, on the equipment. Do not place sources of naked flame, such as burning candles, on the equipment. Do not block the ventilation slots of the equipment with objects such as newspapers, curtains, etc. When installing the equipment, leave some free space around it to provide adequate ventilation. Install the equipment in such a way that the mains supply plug or the connector of the equipment can be easily reached.

Consignes de sécurité

N'exposez pas l'alimentation à des projections ou gouttes d'eau. Ne posez pas d'objets contenant du liquide, tels que des verres, sur l'équipement. Ne mettez pas de source de flamme, comme des bougies, sur l'équipement. Ne bouchez pas les ouvertures de ventilation de l'équipement avec des objets comme des journaux, des rideaux, etc. Installez l'équipement en laissant un espace libre tout autour de lui afin de permettre une ventilation suffisante. Installez l'équipement de telle sorte que la prise d'alimentation d'électricité ou le connecteur de l'équipement soit facilement accessible.



DECLARATION OF CONFORMITY

according to EN ISO/IEC 17050-1:2004

Company Name:

Company Address:

ALCAD, S.L.

Pol. Ind. Arreche-Ugalde, 1
Apdo. 455
20305 IRUN (Guipúzcoa)
SPAIN

declares that the product

Model Number(s):

MB-302, MB-303, MB-304, MB-305, MB-306, MB-308 ML-302,
ML-303, ML-304, ML-305, ML-306, ML-308

Product Description:

MULTISWITCH SYSTEM

Product Option(s):

INCLUDING ALL OPTIONS

Is in conformity with:

Safety: EN 60728-11:2005
EN 60065:2002
EMC: EN 50083-2:2006

Supplementary Information:

The product herewith complies with the requirements of the Low Voltage Directive 2006/95/CE and the EMC Directive 89/336/EEC and their relevant amendments, gathered under the directive 93/68/EEC.

Note: to comply with these directives, do not use the products without covers and operate the system as specified.



Irún, 29 Jun 2012

A handwritten signature in black ink, appearing to read "Anton Galarza".

Anton Galarza
General Manager

Especificaciones sujetas a modificación sin previo aviso

Specifications subject to modifications without prior notice

Les spécifications sont soumises à de possibles modifications sans avis préalable



ALCAD, S.A.

Tel. 943 63 96 60
Fax 943 63 92 66
Int. Tel. +34 - 943 63 96 60
info@alcad.net
Apdo. 455 - Pol. Ind. Arreche-Ugalde, 1
20305 IRUN - Spain

www.alcad.net

FRANCE - Hendaye

Tel. 00 34 - 943 63 96 60

CZECH REPUBLIC - Ostrava cíce

Tel. 546 427 059

UNITED ARAB EMIRATES - Dubai

Tel. 971 4 214 61 40

TURKEY - Istanbul

Tel. 212 295 97 00

AENOR



Empresa
Registrada



ER-0196/1996